



LG K10 Camera Lens Cover Replacement

This guide will show how to replace rear camera lens cover for LG K10. The rear camera lens cover comes with camera lens, power & volume key.

Written By: Eric



LG K10

Rear Camera Cover Assembly



INTRODUCTION

[video: <https://www.youtube.com/watch?v=rpfJpnkBXYw>]

If you encounter the following situations you may need to replace the rear camera cover assembly for LG K10:

The rear camera lens is broken/cracked?

The power button or volume key is not sensitive in LG K10?

The power/volume button is broken?

After a long time usage, problems may occur on the power&volume buttons. your devices may not be able to power on/off or the volume can not be adjusted. DIY to fix it.



TOOLS:

- [Tweezers](#) (1)
- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [LG K10 Rear Camera Cover assembly](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 09:03:23 PM.